



Continuous Strongback Bridging Recommended. Refer to Plans for Placement. Nailed as Indicated With (2) 3" Nails.

Framer is Advised to Install and Nail All Strongbacks Before Installation of the Sub floor.

**Note:
Not Required**

- 9 1/4" Joists - 2x4 Strongback**
- 11 7/8" Joists - 2x4 Strongback Min.**
- 14" Joists - 2x6 Strongback Min.**
- 16" Joists - 2x6 Strongback Min.**

**RECOMMENDED CONTINUOUS
STRONGBACK BRIDGING**

DETAIL No. 5